




# Fenix-Therm 105




EN MANUAL

Introduction .....	18
In the pack .....	19
Installing the thermostat .....	20
How the thermostat works .....	23
Troubleshooting .....	28
Technical specifications .....	29


# Introduction

This is a microprocessor-controlled thermostat for optimum regulation of underfloor heating systems. The front is fitted with a lockable knob for regulating temperature, as well as an on/off switch that shows whether the under-floor heating is in operation.

Temperature control is carried out by means of an algorithm that uses fuzzy technology. The technology entails the thermostat testing and collecting data from start-up, and based on this, calculating when to turn on and off. This technology reduces temperature variations and thus provides a more constant temperature and lower energy consumption. The floor temperature varies less than  $\pm 0.3$  degrees.



# In the pack



- 
1. Front for Elko RS, Elko Plus and Gira
  2. Adapter for Strömfors frame system
  3. Front for Eljo Trend, Merten, Jussi/  
Busch-Jäger
  4. Frame
  5. Thermostat
  6. Floor sensor
  7. Connection clip
- Manual

# Installing the thermostat


The floor sensor should be mounted in a spiral hose laid in the floor. The hose endings should be sealed so that the floor sensor can easily be replaced.

---

## Installation

Mount the thermostat in a 65 mm standard appliance box.

1. Make sure the box is level with the wall.
2. Remove the knob and undo the screw as in the illustration. Lift off front and frame.




3. Connect power, voltage 230 VAC, load and floor sensor cable.

Any extension to the floor sensor cable must be by means of high-voltage current. Protective conductor for incoming feed and for heating cable is connected with a connection clip in the box. See wiring diagram below.

4. Insert the thermostat into the appliance box and screw tight with the existing screws.

5. Mount frame, front and knob.

6. If the thermostat is mounted in a multi-compartment frame, the internal corners of this frame must be removed.



# Getting started


After installation, wait 2-4 weeks before starting the underfloor heating. Precisely how long you wait depends on the type of floor you have and the instructions for the floor putty. Then increase the heat gradually.

In order to adapt the underfloor heating system to your own heating requirements as much as possible, it is important that you read the entire manual.

## How the thermostat works

This section describes all you need to know about how the thermostat works and how you set it.

---



### Turning off and on

The heating is not controlled in stand-by mode. Depress the on/off switch for a second to access stand by mode. Return to normal mode by once again depressing the button for a second.



## Control functions

The thermostat can regulate the temperature in three different ways. This enables the comfort temperature and any flooring temperature requirements to be combined. How the settings are adjusted is described on the next page.

*Floor thermostat (F)* - A sensor in the floor measures the temperature and then regulates the heating accordingly. This is the factory setting.


*Room thermostat (R)* - The thermostat has built-in sensors for measuring the room's temperature and controlling the heating.

*Room and floor thermostat (R&F)* - The built-in sensor regulates the room temperature and the sensor in the floor functions as a floor temperature limiter. The limitation can be set to between 25°C and 45°C. The factory setting is 35 °C.

### Important


In rooms with large windows that are exposed to solar insolation, we recommend the Room and floor thermostat *function*. In rooms with wooden flooring, the *Room and floor thermostat function* must always be used.

The adjustment of the regulating function, must be done by a qualified electrician. The knob and the front first have to be removed. Disconnect from power supply before removing.



Then slide the control to the required position using a small screwdriver.

The overheating protection is adjusted here.



The regulating function is adjusted here.

**F** - Floor thermostat **R** - Room thermostat  
**R&F** - Room and floor thermostat

## Temperature

### *Regulating function*

The thermostat regulates the temperature via a sensor in the floor that measures the temperature and regulates the heating accordingly.

### *Set the temperature required*

Change the floor temperature by turning the knob. Min. position on the control corresponds to 10 °C, max. position corresponds to 45°C. An appropriate setting is usually between 2 and 3.

The temperature does not stabilise until the underfloor heating system has been on for a few days. It might then be necessary to adjust the thermostat's setting.

### **Indication**

The colours on the on/off switch show the current status for the thermostat.

*Red light* - the thermostat is on and the underfloor heating is activated.

*Green light*- the thermostat is on and the underfloor heating is switched off.


## **Delay between turning off and on**

There is a built-in delay in order to avoid unnecessary wear and tear on internal components and to extend the life of the thermostat. If you raise the desired temperature so that the thermostat comes on, and then lower it shortly afterwards, it takes four minutes before it goes off again.

## **Key lock button**

When you have found a suitable setting for the temperature you can lock the knob. This prevents the control being changed accidentally.

See illustration below. First remove the knob. Then move the two plastic parts so that they define the interval required. Replace the knob.



# Troubleshooting

**Important** The underfloor heating system is an electrical power installation and any faults must therefore be remedied by a qualified electrician.

---

## Fault indication

In the event of damage or breakdown of the floor sensor the thermostat switches off and the light starts to flash alternately green and red.

If the floor sensor should be defective it can be replaced, provided that it is installed in a spiral hose laid in the floor as per instructions.

## Test values for floor sensor

The following values apply when the floor sensor's measurements are checked.



Temperature	Resistance
10°C	18,0 kΩ
15°C	14,7 kΩ
20°C	12,1 kΩ
25°C	10,0 kΩ
30°C	8,3 kΩ

# Technical specifications

Voltage	230 VAC-50 Hz
Floor temp. range	10-45 °C
Breaking capacity	16A/230 VAC/Single-pole
Connection cable	max 2.5 mm <sup>2</sup>
Load	$\cos \varphi = 1$
Hysteresis	+/- 0.3 °C
Protection class	IP21
Max. length sensor cable	50 m, 2x1.5 mm <sup>2</sup>

Adapted for Eljo Trend, Elko RS, Elko Plus, Strömfors, Gira, Merten and Jussi/Busch-Jäger frame systems.

EMC certified and can handle an overvoltage of 2,500 VAC.

Approvals:  

Complies with the RoHS and the WEEE Directive.

## Accessories

Art. no.	Article	Dimensions (mm)
E 85 816 71	Sensor cable 3 m (included)	

Zur Wahrung der Garantie muss das Produkt wie in diesem Handbuch beschrieben installiert und betrieben werden. Das heißt, dass das Lesen des Handbuchs sehr wichtig ist. Dies gilt für den Installateur des Thermostats sowie für den Anwender. Darüber hinaus enthält das Handbuch technische Spezifikationen und Informationen zur Fehlerbehebung.

[www.fenixgroup.cz](http://www.fenixgroup.cz)



**Wichtig** Das Fußbodenheizungssystem ist eine elektrische Installation und muss daher unter Einhaltung aller geltenden elektrischen Richtlinien und unter Aufsicht eines qualifizierten Elektrikers installiert werden.